


ELECTRIC CIRCUIT DIAGRAM OF ACTUATOR WITH CURRENT-TYPE TWO-WIRE POSITION TRANSMITTER



M - inductive motor

C - capacitor

WO,WZ - travel switches for opening and closing

WOP,WZP - overload switches for opening and closing

H - brake

NPP - current-type four-wire position transmitter

WO1, WZ1 - additional travel switches
for opening and closing